

# HOW MUCH PER TIRE?

[www.slime.com/calculator](http://www.slime.com/calculator)



4 oz. (118 mL)



8 oz. (237 mL)




4 oz. (118 mL)




8 oz. (237 mL)

- Instantly Seals **Tread Area** Punctures Up to 1/8" (3mm) in Size
- Works Continuously for 2 Years
- Compatible with Schrader and Removable Presta Valves
- Works in Extreme Temperatures
- Non-Flammable & Non-Toxic
- Cleans Up with Water

## HOW DO I INSTALL SLIME?



**1** Position valve in upper half of tire.



**2** Slowly remove valve core with tool in cap.



**3** Allow tire to fully deflate.




**4** Remove object (if possible).


4 oz. ■ 118 mL




**5** Attach hose and squeeze in Slime.



**6** Reinstall valve core.



**7** Just add air.



**8** Spin tire to distribute sealant.