



# 8" PORTABLE CLIP FAN WITH WORKLIGHT

MODEL NO: **SCF8WL**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions

## 1. SAFETY

- ✓ Always read the safety instructions before use.
- ✓ Always ensure this appliance and the USB cord is not damaged.
- ✓ The fan should be used only with the provided USB cable. The fan is rechargeable, and can only be operated in battery mode.
- ✓ Always turn off when not in use.
- ✓ The fan contains a lithium ion battery, and must be charged prior to use.
- ✗ **DO NOT** insert any object to ventilation or exhaust opening as this may damage the product and may cause an electrical shock or fire.
- ✗ **DO NOT** cover fan.
- ✗ **DO NOT** run fan un-attended.
- ✗ **DO NOT** attempt to disassemble, repair, or modify, this will void the warranty. The product should be taken to your local service centre.
- ✗ **DO NOT** use fan for functions other than those described in the instruction manual.
- ✗ **DO NOT** use near inflammable substances or vapour such as alcohol, insecticides, petrol etc.
- ✗ **DO NOT** immerse the fan or the USB cable in any liquid.
- ✗ **DO NOT** Conduct out any electrical repairs, the fan has been built in accordance with relevant safety and performance standards. Only a qualified electrician must carry out all repairs.
- **WARNING!** The fan must be switched off when cleaning.
- **WARNING!** The fan should not be operated by children.
- **WARNING!** plastic wrapping can be a suffocation hazard for babies and young children.
- BATTERY SAFETY INSTRUCTIONS**
- **WARNING!** Powered by a Polymer Lithium-ion battery which can be dangerous if not handled with care.
- ✓ Charge battery prior to first use. The battery pack will have been shipped in a low charge state. Minimum initial charge time 6 hours.  
**Note:** The light and fan do not work when on charge.
- ✗ **DO NOT** charge battery when room temperature is below 50°F (10°C) or above 104°F (40°C).
- ✗ **DO NOT** attempt to recharge the battery by means of a generator or a DC power source.
- ✗ **DO NOT** short-circuit the battery by linking both terminals with a metal object.
- ✗ **DO NOT** store the light in locations where the temperature may exceed 104°F (40°C) such as outside sheds, above heaters, or metal buildings in summer.
- **WARNING!** Dispose of spent battery correctly and in accordance with local regulations.
- ▲ **DANGER! DO NOT** attempt to dismantle the battery pack.
- ✓ For safety and environmental reasons **DO NOT** discard in domestic waste or by burning. **ONLY** discard or recycle according to local waste authority regulations.
- **WARNING! DO NOT** allow a leaking battery to come into contact with skin. If contact with battery fluid occurs take immediate action:  
**Skin contact:** Wash immediately with soap and water. **Eye contact:** Flush eye immediately with cool, clean running water for at least 15 minutes, seek immediate medical attention.

## 2. INTRODUCTION

Portable 8" fan with a light function. Strong clip and magnet base means you can position the fan in any place at any time. It can be used on a desk, in a workshop, in and around the house or even outdoors day or night. It has four, easy-to-use, wind speed options with 360° rotation in all directions. Two light modes are an additional feature. This fan is battery operated and is supplied with a 3.7V 4000mAh battery. It can operate up to 10hrs on a full charge. Supplied with USB-A to USB-C port and cable. It is fully charged within 6hrs. It also has a power bank function with 5V=1A output.




## 3. SPECIFICATION

MODEL NO:	SCF8WL
Fan Diameter:	8"
Height:	250mm
Maximum airflow:	Low/Natural speed - 4.7mph, Medium speed - 6.4mph, High speed - 8.1mph Max Air flow - 4.5m³/s

Power:	8W, Output Power: 5V-1A
Supply:	3.7V 4000mAh battery capacity Polymer Lithium-ion battery

## 4. OPERATION

- ❑ **WARNING! Ensure you read, understand and apply the safety instructions in Section 1 before using the fan.**
  - ❑ **WARNING! DO NOT** clamp the fan to any electrical or sensitive electronic equipment or any surface or object that is too flimsy to resist the force of the spring loaded clamp and/or the weight of the fan.
- 4.1. Mount the fan in a suitable location, using the spring loaded clamp to attach it to a suitable table, shelf or other stable solid surface. Adjust the fan to the desired angle required.
- 4.2. CHARGING THE UNIT**
- ✓ Plug the supplied USB cable into the USB charging port in the back of the fan.
- 4.2.1. The fan will charge when plugged into a USB supply. See fig.1. Allow 6 hours to fully charge. The green LED light will illuminate when charging commences. Subsequent charging times will depend on the state of discharge of the battery.
- 4.3. USING THE FAN**
- 4.3.1. Four fan speed options which are easy to use. Low, Medium, High, and natural speed. A green LED light indicates fan speed. See table below 'Fan speed Operation'.
- 4.4. Select fan speed by pressing the button on the left hand side. See fig.2. See table below for fan speed operation.



FAN SPEED OPERATION		
Press button Once	Power ON/Low Speed	1st green LED light indication light illuminated.
Press button Twice	Medium Speed	2nd green LED light indication light illuminated.
Press button 3 Times	High Speed	3rd green LED light indication light illuminated.
Press button 4 Times	Natural Speed	All green LED lights are illuminated.
Press button 5 Times	Power Off	-

### 4.5. USING THE WORK LIGHT

- 4.5.1. Two work light settings. 50% and 100% brightness options. See table below.
- 4.6. Select the right hand side button indicated in fig.3 for work light brightness settings.

LIGHT OPERATION	
Press button Once	50% brightness.
Press button Twice	On with full brightness.
Press button 3 Times	OFF.


### 4.7. POSITIONING THE WORK LIGHT

- 4.8. Position work light to the desired position using the clip on the base of the fan.
- 4.9. Strong clip and magnet base means you can position the fan in any place at any time.  
**Note:** There is also a thread on the clip for a tripod stand to attach. (Tripod stand not included).



### 4.10. IDENTIFICATION

1.	LED light switch.
2.	LED indicators.
3.	Fan switch.
4.	USB-A output.
5.	Type C charging port.
6.	USB-A to USB-C cable.



## 5. MAINTENANCE

- ✓ Always disconnect the cord from the electrical outlet when cleaning the fan.
- ✓ Dust may accumulate in the grilles after some time and may affect the function. Therefore, it is recommended to clean the fan grille.
- ✓ To remove dust, use mild cleaning agent and soft brush in removing the dust and dirt from the grilles.
- ✗ **DO NOT** submerge the fan in water and **NEVER** allow water to drip into the motor housing.
- ✗ **DO NOT** use solvents or other chemicals to clean the fan.
- ✓ Store the fan in its original box or otherwise cover the fan to protect it from dust.



### ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



REGISTER YOUR  
PURCHASE HERE



### WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**IMPORTANT:** No Liability is accepted for incorrect use of this product.

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



sales@sealey.co.uk



www.sealey.co.uk